
### **BORDFAUX TV STAND**

### Assembly Instructions - Please keep for future reference

PLEASE KEEP THE ORIGINAL PACKAGING UNTIL THE ITEM IS FULLY ASSEMBLED AND IN PLACE. IN THE UNLIKELY EVENT THAT YOU NEED TO RETURN YOUR PRODUCT, IT MUST BE RETURNED IN ITS ORIGINAL PACKAGING TO AVOID FURTHER DAMAGE. FAILURE TO COMPLY TO THESE PROCEDURES, NO RETURN'S WILL BE ACCEPTED.



" SHOULD IT BE NECESSARY TO RETURN THIS PRODUCT FOR ANY REASON, IT MUST BE RETURNED IN ITS ORIGINAL PACKAGING"

## Important: Read carefully

Please check you have all parts listed on your assembly sheet. In the unlikely event that any parts are missing, please contact your retailer immediately.

Do not use any other tools than those listed on your assembly sheet / tools provided.
Use of power tools could damage your product and returns would not be accepted back in these circumstances.
Use of power tools could also make your product unsafe due to overtightening.

Depending on the amount of use your product receives, it may be necessary to tighten the fixings from time to time.


Assemble your product on a soft surface to avoid scratching and also preferably in the room intended for use to avoid having to move the product unnecessarily once assembled.

For cleaning please use a clean damp cloth or duster. Use of abrasive or chemical cleaners will most likely scratch or damage the surface of your product. We do not accept returns for damages arising from incorrect care of products.

Please keep the original packing until your item is fully assembled and in place. In the unlikely event you need to return your product. It must be returned back in its original packing to avoid any damage.

The surface of this item is not heat resistant. Please use a mat under hot, cold or wet items to prevent marking.

# **Exploded View**



# Components - Panels

### Please check that you have all the components listed below before constructing your items.

Part No	Description			
Α	Top Panel	1		
В	Bottom Panel	1		
С	Side Panel L	1		
D	Side Panel R	1		
E	Divider Panel - L	1		
F	Divider Panel - R	1		
G	Adjustable Shelf	1		
Н	Rear Panel	1		
I	Front/Rear Bottom Support	2		
J	Side Bottom Support	2		
K	Side Leg	4		
L	Center Leg	2		
M	Door	2		

# **Components - Fixings**

### Please check that you have all the components listed below before constructing your items.

**Note**: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


(A)	Minifix Cam	(B)	Minifix Bolt	(C)	Minifix Cover	(D)	Dowel M8 x 32mm
	5						
	20 units		20 units		8 units		28 units
(E)	Screw M3 x 12mm	(F)	Screw M10 x 33.5mm	(G)	Screw M4 x 10mm	(H)	Screw M6 x 13mm
							(2)
	4 units		8 units		16 units		6 units
(I)	Shelf Support	(J)	Screw M6.3 x 50mm	(K)	Сар	(L)	Nails
			(d)				
	4 unit		6 units		4 units		20 units
(M)	Screw M4 x 22mm	(N)	Handle	(O)	Allen Key	(P)	Hinge
	2 units		2 units		1 units		4 units
(Q)	Magnet	(R)	Magnet Plate	(S)	Screw M6 x 19mm	(T)	Magnet Support
	2 units		2 units		4 units		2 units


# Tools Required


Ruler - Use this to measure your screws (mm)


0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170


# **Assembly Instructions**



















Step 15





Step 16



# Step 17