


AMELIE 3 DOOR ACCENT SIDEBOARD ASSEMBLY INSTRUCTIONS

Thank you for purchasing the *AMELIE 3 DOOR ACCENT SIDEBOARD*. Please read the instructions carefully to ensure safe operation of the product.




Size: 1162 x 400 x 750mm

PLEASE READ this sheet prior to assembly to familiarise yourself with the various stages of construction.


Carefully open the pack supplied and check the contents against the parts and fittings check list. Do not destroy any of the packaging until you are certain that you have all the necessary parts for the assembly.

CAUTION: There are small components used in the construction of this unit. These loose items should be kept away from young children whilst assembling your unit to avoid the danger of choking hazards.


Tools Required



Person Required



Approximate Assembly Time



**1 Hour
30 Minutes**

IMPORTANT - READ CAREFULLY - RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

INFORMATION

- Due to the size of this product we recommend that it is assembled in the room intended for use.
- When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.
- Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to prevent it from scratching.
- Check the pack and make sure you have all the parts listed.
- Ensure that this product is fully assembled as illustrated before use.
- Check all screws or bolts are tightened and inspect regularly
- This product should only be used on firm, level ground.
- Keep small parts out of reach of children.
- Make sure the legs remain in contact with the ground.
- Tools not included.

WARNINGS

- DO NOT use power tools to construct this product.
- DO NOT over tighten screws or bolts.
- DO NOT use this product if parts are missing, damaged or worn.
- DO NOT sit or stand on the product.
- It is essential that this unit is fixed to the wall with the brackets provided for safety reasons. NB wall fixings are not included. Please source suitable fixings for your wall type. If in doubt please consult a qualified tradesperson.
- WARNING : Always ensure the area to be drilled is free from hidden electrical wires, water or gas pipes.

CARE INFORMATION


- Never use scourers, abrasives or chemical cleaners.
- To clean wipe with a sponge and warm soapy water. Do not use solvent based cleaners or detergents as they can bleach or damage the product.

Please check the pack contents before assembling the product. If any components are missing, please contact your retailer. The fittings pack contains small items that should be kept away from small children.



Parts

CODE	PART NAME	QTY	DIMENSION
A	Side Panel - L	1	14 x 365 x 715mm
B	Side Panel - R	1	14 x 365 x 715mm
C	Top Panel	1	28 x 398 x 1161mm
D	Bottom Panel	1	14 x 365 x 1091mm
E	Back Leg	1	14 x 79 x 1091mm
F	Middle Panel	1	14 x 363 x 621mm
G	Adjustable Shelf	1	14 x 362 x 710mm
H	Adjustable Shelf	1	14 x 362 x 365mm


CODE	PART NAME	QTY	DIMENSION
I	Top Support	1	28 x 35 x 1021mm
J	Front Profile	1	25 x 96 x 1150mm
K	Door Panel	3	14 x 335 x 581mm
L	Side Profile - L	1	14 x 50 x 620mm
M	Side Profile - R	1	14 x 50 x 620mm
	Back Panel Top	1	3 x 395 x 1117mm
	Back Panel Bottom	1	3 x 249 x 1117mm




Fixings (to scale)




Fixings (not to scale)









Layout Parts on Soft Surface





STEP 1





STEP 2






STEP 3





STEP 4




STEP 5





STEP 6



STEP 7




STEP 8




STEP 9

H		2 x	M		2 x
----------	---	-----	----------	---	-----






STEP 10



H		2 x	D		3 x
----------	---	-----	----------	---	-----




STEP 11




STEP 12



STEP 13




STEP 14



STEP 15

B

2 x



STEP 16

C

5 x


H

2 x



M





2 x



STEP 17





STEP 18



STEP 19


K		5 x	H		2 x
----------	---	-----	----------	---	-----






WARNING : THE FRONT NAIL LEG MUST FIX AT 10MM FROM FRONT.

STEP 20



D		4 x
----------	---	-----



STEP 21






STEP 22






Do not tighten

STEP 23



STEP 24




STEP 25


J











20 x



PLEASE ENSURE THAT EACH OF THE FOUR CORNERS OF THE CABINET IS SQUARE.




STEP 26




NOTE : Wall fixing are not supplied with this product as different wall materials require different types of fixing devices (such as Rawl plugs on brick work). You must use fixing devices suitable for the type of wall you intend to mount this product to. Please ensure that the head of any screw used has a diameter greater than the diameter of the mounting hole on the product and that the fixing is safe and secure before use.

The brackets and screws which to fix the strap on to the furniture are only supplied.



STEP 27




STEP 28



STEP 29





IMPORTANT ENSURE TYPE "P" BRACKET IS SELECTED FOR THESE DOOR




STEP 30


8 x



A. Lateral adjustment (Moving Door Left-Right) by screw adjusting





B. Vertical adjustment (Moving Door Up-Down) via slot in the mounting plate





C. Front-to-back adjustment (Spacing Door Off Carcas) by slacking the hinge arm mounting screw


STEP 31



STEP 32





IMPORTANT ENSURE TYPE "Q" BRACKET IS SELECTED FOR THESE DOOR




STEP 33


4 x 



A. Lateral adjustment (Moving Door Left-Right) by screw adjusting





B. Vertical adjustment (Moving Door Up-Down) via slot in the mounting plate



C. Front-to-back adjustment (Spacing Door Off Carcas) by slacking the hinge arm mounting screw

STEP 34


- F  2 x
- O  1 x



Complete Assembly

Your *AMELIE 3 DOOR ACCENT SIDEBOARD* is now completely assembled.

Periodically check to ensure that the components are in proper position, free from damage. Also, make sure the connectors are tight and secure.



Keep instructions for future reference

