
LEON 2 DOOR TV UNIT ASSEMBLY INSTRUCTIONS



FOR DOMESTIC USE ONLY IMPORTANT PLEASE READ BEFORE YOU CONTINUE FURTHER

THE PRODUCT YOU HAVE PURCHASED WILL GIVE YOU MANY YEARS OF SERVICE IF YOU FOLLOW THE GUIDELINES FOR ITS SAFE ASSEMBLY AND PERIODIC MAINTENANCE AND CLEANING.

ASSEMBLE ON A SOFT CLEAN SURFACE.

DO NOT USE ANY TOOLS OTHER THAN THOSE SHOWN.


ANY SPANNERS OR ALLEN KEYS REQUIRED ARE INCLUDED WITH THE FITTING KIT.

DO NOT FOR ANY REASON USE A POWER TOOL TO ASSEMBLE THIS PRODUCT. ITS USE WILL INVALIDATE ANY CLAIM YOU MAY HAVE AND COULD MAKE THIS PRODUCT UNSAFE.

DEPENDING ON THE AMOUNT OF USE THIS PRODUCT RECEIVES, IT MAY BE NECESSARY TO TIGHTEN UP THE FIXINGS FROM TIME TO TIME. THIS IS COMPLETELY NORMAL FOR ANY FLAT PACK FURNITURE. <u>DO NOT OVERTIGHTEN FIXINGS</u>.

FOR CLEANING, YOU MAY USE A DAMP CLOTH (NOT WET). <u>DO NOT USE POLISH</u>, <u>DETERGENT OR CHEMICAL CLEANERS</u>.

THIS SURFACE OF THIS ITEM IS NOT HEAT RESISTANT. ALWAYS USE A PLACE MAT UNDER HOT OR COLD ITEMS TO PREVENT MARKING.




PART LIST


Part Number	Part Code	Part Description	Quantity	Carton
1	S300-305-055-ZF1-01	Right Side Panel	1	1/1
2	S300-305-055-ZF1-02	Left Side Panel	1	1/1
3	S300-305-055-ZF1-03	Right Centre Panel	1	1/1
4	S300-305-055-ZF1-04	Top Panel	1	1/1
5	S300-305-055-ZF1-05	Adjustable Shelf Panel	1	1/1
6	S300-305-055-ZF1-06	Left Centre Panel	1	1/1
7	S300-305-055-ZF1-07	Right Door	1	1/1
8	S300-305-055-ZF1-08	Left Door	1	1/1
9	S300-305-055-ZF1-09	Bottom Panel	1	1/1
10	S300-305-055-ZF1-10	Back Panel	1	1/1

HARDWARE LIST

No	Part Name		Qty	Carton
Α	M8x30mm Wooden Dowel		x16	1
В	Minifix Cam Bolt (8032t)	O TOO PA TOOM	x8	1
С	Minifix Cam Nut (1512)		x8	1
D	M3.5x16mm Screw	WITTE	x20	1
Е	M4x45mm Screw	Management	x8	1
F	Iron Leg (150mm) - Black		x5	1
G	20mm Handle Screw	annumb	x4	1
Н	Handle (64mm)		x2	1
ı	Metal Door	S	x4	1
J	Corner Support (AC101)		x2	1
K	M4x20mm Screw	Manage	x4	1
L	M3.5x14mm Screw	80mm	x2	1
М	Magnet		x2	1
N	Plate	<u></u>	x2	1
0	Nail		x8	1
Р	Iron Shelf Support		x4	1


TIPS FOR FITTINGS CAM-LOCKS





Cam bolt head needs to be in centre

CAMBOLT




PARTS REQUIRED

1 - RIGHT SIDE PANEL x1

x1


2 - LEFT SIDE PANEL


HARDWARE REQUIRED





TOOLS REQUIRED





STEP 2

PARTS REQUIRED


3 - RIGHT CENTRE PANEL x1


6 - LEFT CENTRE PANEL x1

HARDWARE REQUIRED

A 08

P 04





PARTS REQUIRED


4 - TOP PANEL x1


HARDWARE REQUIRED



M 02

TOOLS REQUIRED







STEP 4


PARTS REQUIRED

7 - RIGHT DOOR	x1
8 - LEFT DOOR	x1

HARDWARE REQUIRED









PARTS REQUIRED

1 - RIGHT SIDE PANEL	x1
2 - LEFT SIDE PANEL	x1
3 - RIGHT CENTRE PANEL	x1
4 - TOP PANEL	x1
6 - LEFT CENTRE PANEL	x1

HARDWARE REQUIRED


TOOLS REQUIRED






STEP 6


PARTS REQUIRED




HARDWARE REQUIRED




PARTS REQUIRED







HARDWARE REQUIRED



TOOLS REQUIRED






STEP 8

PARTS REQUIRED


9 - BOTTOM PANEL x1




HARDWARE REQUIRED







PARTS REQUIRED





HARDWARE REQUIRED






TOOLS REQUIRED





STEP 10

PARTS REQUIRED




HARDWARE REQUIRED










PARTS REQUIRED

5 - ADJUSTABLE SHELF PANEL x1



HARDWARE REQUIRED

TOOLS REQUIRED

