
RANKIN - WRITTING DESK ASSEMBLY INSTRUCTIONS

Thank you for purchasing the **WRITTING DESK** Please read the instructions carefully to ensure safe operation of the product.



IMPORTANT - READ CAREFULLY - RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

INFORMATION

- This product is intended for a maximum weight of **16kgs** and a load capacity of 5kg for each drawer. Do not exceed this weight.
- Due to the size of this product we recommend that is assembled in the room intended for use.
- When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly
- Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to prevent it from scratching.
- Check the pack and make sure you have all the parts listed.
- Ensure that this product is fully assembled as illustrated before use.
- Check all screws or bolts are tightened and inspect regularly.
- This product should only be used on firm, level ground.
- Keep small parts out of reach of children.
- Make sure the legs remain in contact with the ground.
- Tools not included.

WARNINGS

- DO NOT use power tools to construct this product.
- DO NOT over tighten screw or bolts.
- DO NOT use this product if parts are missing, damage or worn.
- DO NOT stand or sit on this 1 drawer writing desk.
- We recommend the use of the wall safety bracket provided for safety reasons. N.B. Wall fixings suitable for a solid wall are included although the wall plug provided may not be suitable for other type of walls such as hollow walls. Fixings suitable for your wall type must be obtained separately.. If in doubt please consult a qualified trade person. **Warning:** Always ensure the area to be drilled is free from

If in doubt please consult a qualified trade person. **Warning:** Always ensure the area to be drilled is free from hidden electrical wires, water and gas pipes.


CARE INFORMATION


- Never use scourers, abrasives or chemical cleaners.
- To clean wipe with a sponge and soapy water. Do not use solvent based cleaners or detergents as they can bleach or damage the product.


Please check the pack contents before assembling the product. If any components are missing, please contact your retailer. The fittings pack contains small items that should be kept away from small children.


Parts


CODE	PART NAME	QTY
Α	Side Panel (L) (15 x 390 x 740mm)	1
В	Side Panel (R) (15 x 390 x 740mm)	1
С	Top Panel (15 x 396 x 900mm)	1
D	Back Panel (Top) (15 x 195 x 866mm)	1
E	Drawer Front (18 x 110 x 858mm)	1
F	Drawer Side (L) (12 x 75 x 290mm)	1
G	Drawer Side (R) (12 x 75 x 290mm)	1
Н	Drawer Back (12 x 75 x 818mm)	1
I	Drawer Support (12 x 60 x 278mm)	2
J	Back Panel (Bottom) (15 x 195 x 866mm)	1
Z	Drawer Bottom (2.5 x 287 x 827mm)	1


























Complete Assembly

Your **WRITTING DESK** is now completely assembled.

Periodically check to ensure that the components are in their proper position, free from damage. Also, make sure the connectors are tight and secure.

