
# WAVERLEY 4` STORAGE BED ASSEMBLY INSTRUCTIONS



### FOR DOMESTIC USE ONLY IMPORTANT

#### PLEASE READ BEFORE YOU CONTINUE FURTHER

THE PRODUCT YOU HAVE PURCHASED WILL GIVE YOU MANY YEARS OF SERVICE IF YOU FOLLOW THE GUIDELINES FOR ITS SAFE ASSEMBLY AND PERIODIC MAINTENANCE AND CLEANING.

ASSEMBLE ON A SOFT CLEAN SURFACE.

DO NOT USE ANY TOOLS OTHER THAN THOSE SHOWN.

ANY SPANNERS OR ALLEN KEYS REQUIRED ARE INCLUDED WITH THE FITTINGS KIT.

DO NOT FOR ANY REASON USE A POWER TOOL TO ASSEMBLE THIS PRODUCT. ITS USE WILL INVALIDATE ANY CLAIM YOU MAY HAVE AND COULD MAKE THIS PRODUCT UNSAFE.

DEPENDING ON THE AMOUNT OF USE THIS PRODUCT RECEIVES IT MAY BE NECESSARY TO TIGHTEN UP THE FIXINGS FROM TIME TO TIME. THIS IS COMPLETELY NORMAL FOR ANY FLAT PACK FURNITURE.


DO NOT OVERTIGHTEN FIXINGS.

FOR CLEANING YOU MAY USE A DAMP CLOTH (NOT WET).

THIS PRODUCT MAY STAIN OR MARK IF ALLOWED TO COME INTO CONTACT WITH WET OR DAMP OBJECTS AS MATERIALS USED HAVE NOT BEEN SCOTCH GUARDED.


### **Important information!**

The gas lifts used in the construction of this product are extremely strong and cannot be operated by hand when not fitted to the ottoman hinges. All gas lifts are tested in the factory for correct pressure and operation before use.



You must ensure the MATTRESS is on the bed frame before lifting the mechanism.







Initially it might appear that the gas lifts are very stiff when opening and closing the ottoman frame, THIS IS NORMAL.


After operating the ottoman a few times, the movement of the gas lifts and the opening and closing of the ottoman will become easier.

Parts List							
A:HEADBOARD 1PC		B:FOOTBOARD 1PC		C:SIDE RAIL 2PCS LEFT AND RIGHT		D: FRAME KD 1SETS  D4  D1  D2  D1  D3	
E:SLAT 24PCS		F:CORNER BRACKET 2PCS		G:GAS LIFT 2PCS		H:HINGES  LEFT AND RIGHT 2PCS	
SUPPORT BLOCK 2PCS		J : CROSS BAR 1PC		K: FEET 4PCS		L : SIDEBAR 2PCS	
M : NON-WOVEN BED BASE 1PC							
Hardware List							
1:BOLT 16PCS  M8X45mm	2:BOLT 8PCS  M8X30mm		3:BOLT 8PCS  M6X40mm	4:BOLT 12PCS	5:BOLT 4PCS  M8X55mm		6:NUT 12PCS
7:FLAT WASHER 28PCS	8:SPRING WASHER 28PCS  M8			10:SPANNER 1PC	11:SLAT CAP 24PCS		12:DOUBLE PLASTIC CAP 12PCS
13:METAL PLATE 1PC	14:ALLEN KEY  1PC  M6		15:FLAT WASHER 20PCS M6	16:spring washer 20pcs  M6	17 1PC		






PAGE 5 OF 7



#### STEP 6

Assembly Instructions
Please ensure the pneumatic arm is the correct orientation. The thinner section should be attached to the side rail. and the thicker part is connected to the slat frame. secure the pneumatic lifting mechanisms on the side rails place by using flange nuts as shown.

Do not overtighten the nuts.



#### STEP 7

### <u>M <> 1PC</u>

# Assembly Instructions 1: Attach woven fabric

1: Attach woven fabric Turn bed on its side and attach woven fabric (M) to base.

Please note: Before lowering the slat frame Into position, place the mattress on the slat frame. The weight of the mattress will help with the lowering of the frame.

Mattress weight limit: 50kgs.

Assembly is completed.

