


NEVADA 1 DOOR 1 DRAWER WARDROBE ASSEMBLY INSTRUCTIONS






IMPORTANT FOR DOMESTIC USE ONLY

PLEASE READ BEFORE YOU CONTINUE FURTHER

CARE AND MAINTENANCE

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.




PARTS LIST

























Please Note:
The below parts have all been stamped with the part number to help identify them during assembly.

Part Number	Part Description	Quantity	Carton
01	Base-Top Panel	2	1/1
02	Right Side Panel	1	1/1
03	Left Side Panel	1	1/1
04	Shelf	1	1/1
05	Door	1	1/1
06	Front Baseboard	1	1/1
07	Back Baseboard	1	1/1
08	Frame	1	1/1
09	Back Panel	1	1/1
10	Drawer Front	1	1/1
11	Drawer Side	2	1/1
12	Drawer Back Panel	1	1/1
13	Drawer Botom	1	1/1

TOOLS REQUIRED




FITTINGS LIST

<p>A</p>  <p>Flat Head Screw Ø6,0 x 10mm (4x)</p> <p>1/+</p>	<p>B</p>  <p>Flan Head Screw Ø4,0 x 14mm (3x)</p> <p>2/+</p>	<p>C</p>  <p>Flat Head Screw Ø4,0 x 14mm (22x)</p> <p>2/+</p>	<p>D</p>  <p>Flan Head Screw Ø4,0 x 22mm (4x)</p> <p>1/+</p>
<p>E</p>  <p>Flat Head Screw Ø4,0 x 50mm (18x)</p> <p>2/+</p>	<p>F</p>  <p>Dowel Ø6,0 x 30mm (28x)</p> <p>2/+</p>		<p>G</p>  <p>Nail 10 x 10 (46x)</p> <p>2/+</p>
<p>H</p>  <p>Flan Head Screw Ø3,5 x 30mm (1x)</p> <p>1/+</p>	<p>I</p>  <p>'L' Metallic Support (4x)</p> <p>1/+</p>	<p>J</p>  <p>Washer (2x)</p> <p>1/+</p>	<p>K</p>  <p>Plastic Foot (4x)</p> <p>1/+</p>
<p>L</p>  <p>Hanging Rail Support (2x)</p>	<p>M</p>  <p>Hinge (3x)</p>	<p>N</p>  <p>Hinge Plate (3x)</p>	<p>O</p>  <p>Strap (1x)</p>
<p>P</p>  <p>Handle (2x)</p>	<p>Q</p>  <p>Hole Plugs (16x)</p> <p>2/+</p>	<p>R</p>  <p>Glue (1x)</p>	<p>S</p>  <p>Cam Nut (2x)</p> <p>1/+</p>
<p>T</p>  <p>Cam Bolt (2x)</p> <p>1/+</p>	<p>U</p>  <p>Flat Head Screw Ø4,0 x 12mm (8x)</p> <p>2/+</p>	<p>V</p>  <p>Drawer Runners (1x)</p>	
<p>X</p>  <p>Hanging Rail (1x)</p>		<p>Y</p>  <p>Hole Plugs (2x)</p> <p>2/+</p>	

TIPS FOR FITTINGS CAM-LOCKS

WHEN FITTING CAM NUT. ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE


✓



↑


CORRECT

✗



↑




WRONG



Cam bolt head needs to be in centre

CAMBOLT

Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)





STEP 1

PARTS REQUIRED


3 - LEFT SIDE PANEL x1

HARDWARE REQUIRED




A  02
Ø6,0 x 10mm

G  02
10 x 10

K  02

V  01
LEFT

TOOLS REQUIRED





STEP 2


PARTS REQUIRED


2 - RIGHT SIDE PANEL x1

HARDWARE REQUIRED




A  02
Ø6,0 x 10mm

G  02
10 x 10

K  02

V  01
RIGHT

TOOLS REQUIRED




STEP 3

ATTACH THE HINGES TO PART 3 (LEFT) TO HANG THE DOOR FROM THE LEFT.

PARTS REQUIRED

3 - LEFT SIDE PANEL x1



HARDWARE REQUIRED

C  08
Ø4,0 x 14mm

L  01

N  03

TOOLS REQUIRED




STEP 4


ATTACH THE HINGES TO PART 2 (RIGHT) TO HANG THE DOOR FROM THE RIGHT.

PARTS REQUIRED



2 - RIGHT SIDE PANEL x1

HARDWARE REQUIRED

C  02
Ø4,0 x 14mm

L  01

TOOLS REQUIRED







STEP 5



PARTS REQUIRED

1A - TOP PANEL	x1
1B - BASE PANEL	x1
4 - SHELF	x1

HARDWARE REQUIRED

F	 Ø6,0 x 30mm	12
I		02
R	 Glue	01
U	 Ø4,0 x 12mm	02

TOOLS REQUIRED





STEP 6



PARTS REQUIRED

6 - FRONT BASEBOARD	x1
7 - BACK BASEBOARD	x1

HARDWARE REQUIRED

F	 Ø6,0 x 30mm	08
R	 Glue	01

TOOLS REQUIRED





STEP 7



PARTS REQUIRED

- 1A - TOP PANEL x1
- 1B - BASE PANEL x1
- 2 - RIGHT SIDE PANEL x1
- 4 - SHELF x1

HARDWARE REQUIRED

- E  06
Ø4,0 x 50mm
- R  01


TOOLS REQUIRED





STEP 8

PARTS REQUIRED



- 6 - FRONT BASEBOARD x1
- 7 - BACK BASEBOARD x1
- 3 - LEFT SIDE PANEL x1



HARDWARE REQUIRED

- E  10
Ø4,0 x 50mm
- R  01


TOOLS REQUIRED



STEP 9


PARTS REQUIRED

9 - BACK PANEL x1





HARDWARE REQUIRED

B  03
Ø4,0 x 14mm





G  04
10 x 10

TOOLS REQUIRED




IMPORTANT PLEASE FOLLOW !

Please make sure Part 9 is lined up correctly at the top before placing fitting H into the panel as this can affect the alignment of the doors once assembled.



Detail 13




Detail 14

IMPORTANT PLEASE FOLLOW !


Please make sure Part 9 isn't overhanging at the sides before you screw fitting B into the plinth.

STEP 10




PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED




Detail 13


STEP 11


PARTS REQUIRED

8 - FRAME x1






HARDWARE REQUIRED


I  02

U  06
Ø4,0 x 12mm

TOOLS REQUIRED




Detail 15



Align corners



STEP 12

PARTS REQUIRED



HARDWARE REQUIRED

X  01



Detail 16


STEP 13

PARTS REQUIRED


11 - DRAWER SIDE x2

12 - DRAWER BACK PANEL x1

HARDWARE REQUIRED

F  08
Ø6,0 x 30mm

R  01




STEP 14



PARTS REQUIRED

10 - DRAWER FRONT x1

HARDWARE REQUIRED

T  02

TOOLS REQUIRED




STEP 15

PARTS REQUIRED



11 - DRAWER SIDE x2

12 - DRAWER BACK PANEL x1

HARDWARE REQUIRED


E  02
Ø4,0 x 50mm

TOOLS REQUIRED





STEP 16

PARTS REQUIRED





HARDWARE REQUIRED

Y  02

R  01

S  02


TOOLS REQUIRED




STEP 17

PARTS REQUIRED




13 - DRAWER BOTTOM x1




HARDWARE REQUIRED

G  04
10 x 10

TOOLS REQUIRED




Detail 18




STEP 18




PARTS REQUIRED




HARDWARE REQUIRED

G  04
10 x 10

TOOLS REQUIRED




Detail 18






STEP 19



PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED





STEP 20




PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED



STEP 21

PARTS REQUIRED


5 - DOOR x1





HARDWARE REQUIRED

Q  16


TOOLS REQUIRED



POSITION THE DOOR TO THE LEFT OR RIGHT SIDE




Detail 20




Detail 21

STEP 22

PARTS REQUIRED




HARDWARE REQUIRED




D  04
Ø4,0 x 20mm

P  02

TOOLS REQUIRED





See the last page




Detail 22

STEP 23





PARTS REQUIRED




HARDWARE REQUIRED




TOOLS REQUIRED





Height Adjustment



Internal Adjustment



Depth Adjustment



WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices.

Please make sure you use fixings suitable for the walls in your home.

