


# NEVADA 2 DOOR CORNER WARDROBE ASSEMBLY INSTRUCTIONS




## **IMPORTANT FOR DOMESTIC USE ONLY**

**PLEASE READ BEFORE YOU CONTINUE FURTHER**


## **CARE AND MAINTENANCE**

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.



After assembly use an alcohol based product/cleaner to erase the numbers printed on the parts that are visual.




### PARTS LIST

**Please Note:**




























The below parts have all been stamped with the part number to help identify them during assembly.

Part Number	Part Description	Quantity	Carton
1	Base Panel	1	3/3
2	Angled Base Panel	1	3/3
3	BackBoard	1	1/3
4	Large Back Panel	1	1/3
5	Small Back Panel	2	1/3
6	Division Panel	1	2/3
7	Right Side Panel	1	1/3
8	Left Side Panel	1	1/3
9	Right Door	1	2/3
10	Left Door	1	2/3
11	Upper Frame	1	3/3
12	Large Shelf	1	3/3
13	Small Shelf	1	2/3
14	Ajustable Shelf	4	2/3
15	Front Baseboard	1	3/3
16	Back Baseboard	1	3/3
17	Large Back Baseboard	1	3/3
18	Top Panel	1	3/3
19	Angled Top Panel	1	3/3
20	Internal Baseboard	1	3/3

**TOOLS REQUIRED**






## FITTINGS LIST




<p><b>A</b></p>  <p>Flat Head Screw Ø4,0 x 14mm (53x)</p> <p>+/2</p>	<p><b>B</b></p>  <p>Flat Head Screw Ø4,0 x 50mm (29x)</p> <p>+/2</p>	<p><b>C</b></p>  <p>Cam Bolt (6x)</p> <p>+/1</p>	
<p><b>D</b></p>  <p>Hole Plugs (16x)</p> <p>+/2</p>	<p><b>E</b></p>  <p>Flat Head Screw M4 x 20 (5x)</p> <p>+/1</p>	<p><b>F</b></p>  <p>Flat Head Screw Ø3,5 x 40mm (5x)</p> <p>+/1</p>	<p><b>G</b></p>  <p>Nail 10 x 10 (125x)</p> <p>+/2</p>
<p><b>H</b></p>  <p>Cam Nut (12x)</p> <p>+/2</p>	<p><b>I</b></p>  <p>Flat Head Screw Ø4,0 x 25mm (13x)</p> <p>+/2</p>	<p><b>J</b></p>  <p>Dowel Ø6,0 x 30mm (34x)</p> <p>+/2</p>	<p><b>K</b></p>  <p>Dowel Ø6,0 x 40mm (4x)</p> <p>+/1</p>
<p><b>L</b></p>  <p>'L' Metallic Support (11x)</p> <p>+/1</p>	<p><b>M</b></p>  <p>Hanging Rail Support (2x)</p>	<p><b>N</b></p>  <p>Glue (1x)</p>	<p><b>O</b></p>  <p>Washer (4x)</p> <p>+/1</p>
<p><b>P</b></p>  <p>Strap (2x)</p>	<p><b>Q</b></p>  <p>Flat Head Screw Ø3,5 x 30mm (2x)</p> <p>+/1</p>	<p><b>R</b></p>  <p>Plastic Foot (12x)</p> <p>+/1</p>	<p><b>S</b></p>  <p>Hinge Plate (6x)</p>
<p><b>T</b></p>  <p>Handle (2x)</p>	<p><b>U</b></p>  <p>Hinge (6x)</p>	<p><b>V</b></p>  <p>Shelf Support (18x)</p> <p>+/2</p>	<p><b>W</b></p>  <p>Central Hanging Rail Support (1x)</p>
<p><b>X</b></p>  <p>Angular Metallic Support (1x)</p>	<p><b>Y</b></p>  <p>Hanging Rail (1x)</p>	<p><b>Z</b></p>  <p>Back Panel Strip (1x)</p>	<p><b>A1</b></p>  <p>Hole Plugs (38x)</p> <p>+/2</p>

### TIPS FOR FITTINGS CAM-LOCKS

WHEN FITTING CAM NUT. ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE



**CAMBOLT**  
Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)



# STEP 1

## PARTS REQUIRED

2 - ANGLED BASE x1


12 - LARGE SHELF x1

13 - SMALL SHELF x1



19 - ANGLED TOP x1

## HARDWARE REQUIRED

J  12

N  01

## TOOLS REQUIRED



# STEP 2

## PARTS REQUIRED

1 - RECTANGLE BASE x1

18 - RECTANGLE TOP x1



## HARDWARE REQUIRED

J  04

K  04

N  01

## TOOLS REQUIRED



# STEP 3

## PARTS REQUIRED

15 - FRONT BASEBOARD x1


16 - BACK BASEBOARD x1

17 - LARGE BACK BASEBOARDx1

19 - ANGLED TOP PANEL x1

20 - INTERNAL BASEBOARD x1



## HARDWARE REQUIRED

A  12  
Ø4,0 x 14mm

L  11

X  01

## TOOLS REQUIRED



Please note pre-drill

# STEP 4

## PARTS REQUIRED

15 - FRONT BASEBOARD x1

16 - BACK BASEBOARD x1


17 - LARGE BACK BASEBOARDx1

20 - INTERNAL BASEBOARD x1

## HARDWARE REQUIRED



G  08

J  10

N  01

R  08

## TOOLS REQUIRED




# STEP 5

## PARTS REQUIRED

8 - LEFT SIDE PANEL x1


## HARDWARE REQUIRED

A  06  
Ø4,0 x 14mm






G  02

R  02

S  03

V  08

## TOOLS REQUIRED



# STEP 6

## PARTS REQUIRED

7 - RIGHT SIDE PANEL x1

## HARDWARE REQUIRED

A  08  
Ø4,0 x 14mm






G  02

M  01

R  02

S  03

## TOOLS REQUIRED



# STEP 7

## PARTS REQUIRED

6 - DIVISION PANEL x1



## HARDWARE REQUIRED

J  04

N  01

V  10

## TOOLS REQUIRED



# STEP 8

## PARTS REQUIRED

3 - BACKBOARD x1




## HARDWARE REQUIRED

A  02  
Ø4,0 x 14mm

J  04

M  01

## TOOLS REQUIRED



# STEP 9


## PARTS REQUIRED


1 - BASE PANEL x1

3 - BACKBOARD x1





12 - LARGE SHELF x1

## HARDWARE REQUIRED

B  04  
Ø4,0 x 50mm

N  01

## TOOLS REQUIRED




# STEP 10


## PARTS REQUIRED


7 - RIGHT SIDE PANEL x1

18 - TOP PANEL x1







## HARDWARE REQUIRED

B  08  
Ø4,0 x 50mm

N  01


## TOOLS REQUIRED






# STEP 11



**PARTS REQUIRED**



**HARDWARE REQUIRED**



**TOOLS REQUIRED**




# STEP 12


**PARTS REQUIRED**

2 - ANGLED BASE PANEL x1



19 - ANGLE TOP PANEL x1



**HARDWARE REQUIRED**




**TOOLS REQUIRED**




# STEP 13

## PARTS REQUIRED




6 - DIVISION PANEL x1



## HARDWARE REQUIRED


B  04  
Ø4,0 x 50mm

## TOOLS REQUIRED





# STEP 14

## PARTS REQUIRED







## HARDWARE REQUIRED

A  01  
Ø4,0 x 14mm

F  05  
Ø3,5 x 40mm

W  01

## TOOLS REQUIRED




# STEP 15


## PARTS REQUIRED


16 - BACK BASEBOARD x1

17 - LARGE BACK BASEBOARD x1





## HARDWARE REQUIRED

B  Ø4,0 x 50mm 02

N  01

## TOOLS REQUIRED




# STEP 16

## PARTS REQUIRED


8 - LEFT SIDE PANEL x1


13 - SMALL SHELF x1

20 - INTERNAL BASEBOARD x1





## HARDWARE REQUIRED

B  Ø4,0 x 50mm 08


N  01

## TOOLS REQUIRED




# STEP 17



**PARTS REQUIRED**



**HARDWARE REQUIRED**



**TOOLS REQUIRED**




# STEP 18


**PARTS REQUIRED**

11 - UPPER FRAME x1



15 - FRONT BASEBOARD x1



**HARDWARE REQUIRED**




**TOOLS REQUIRED**





# STEP 19


## PARTS REQUIRED




## HARDWARE REQUIRED

B	 Ø4,0 x 50mm	02
Y		01



## TOOLS REQUIRED



### Detail 23




### Detail 9




# STEP 20

## PARTS REQUIRED

4 - LARGE BACK PANEL x1




## HARDWARE REQUIRED





B  01  
Ø4,0 x 50mm

G  22


## TOOLS REQUIRED




\* For your future reference  
Order Number should be here



Detail 16



Detail 9



ATTACH THE FIRST NAILS  
IN THE ORDER SHOWN

# STEP 21


### PARTS REQUIRED



### HARDWARE REQUIRED

### TOOLS REQUIRED



5 - SMALL BACK PANEL x2

G  82

Z  01




ATTACH THE FIRST 5 NAILS, THEN INSERT THE BACK PANEL STRIP AND FIT THE OTHER BACK PANEL, ATTACH THE OTHER 5 NAILS AND FINISH BY ATTACHING THE REST OF THE NAILS TO THE PRODUCT(NEXT STEP).



# STEP 22




## PARTS REQUIRED



## HARDWARE REQUIRED




## TOOLS REQUIRED





# STEP 23

**PARTS REQUIRED**




**HARDWARE REQUIRED**



D		16
A1		34

14 - ADJUSTABLE SHELF x4

Detail 20



Detail 24




# STEP 24

## PARTS REQUIRED

9 - RIGHT DOOR x1




10 - LEFT DOOR x1

## HARDWARE REQUIRED

A  12  
Ø4,0 x 14mm

U  06

## TOOLS REQUIRED




# STEP 25


## PARTS REQUIRED

9 - RIGHT DOOR x1



10 - LEFT DOOR x1



## TOOLS REQUIRED




**!**  
Please note the top or bottom edges of the doors are labelled LEFT or RIGHT to make them easier to identify when assembling.





# STEP 26


## PARTS REQUIRED





## HARDWARE REQUIRED

E		M4x20mm	04
T			02


## TOOLS REQUIRED




**TIP**  
If desired, after assembly use an alcohol cleaner to erase the number printed on the parts.


### Detail 22





### Height Adjustment



### Internal Adjustment




### Depth Adjustment




# STEP 27


## PARTS REQUIRED




## HARDWARE REQUIRED




## TOOLS REQUIRED



Detail 23



**Please note:  
Pre-marked  
Holes**



## WARNING

**Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.**

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices.

Please make sure you use fixings suitable for the walls in your home.

