


# MADRID BOOKCASE ASSEMBLY INSTRUCTIONS




## **IMPORTANT FOR DOMESTIC USE ONLY**

**PLEASE READ BEFORE YOU CONTINUE FURTHER**

# **CARE AND MAINTENANCE**

- After unpacking this product please keep the original packaging in case it needs to be returned for any reason.
- Please ensure all fittings and parts are present before commencing with assembly.
  - Never drag or push products as this could cause damage to the joints making it inferior.
  - We strongly recommend that you keep children away from your work area.
  - We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
  - Assemble this product as close to its final position as possible.
  - Do not place this product next to a radiator or in direct sunlight.
  - Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
  - Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
  - Make sure any spillage is wiped off immediately.
  - Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
  - For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
  - From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
  - Do not place on a wet or damp floor as staining may occur to your floor.






















## PARTS LIST

***Please Note:***

The below parts have all been stamped with the part number to help identify them during assembly.



Part Number	Part Code	Part Description	Quantity	Carton
1	S300-306-048-AL1-01	Left Side Panel	1	1/2
2	S300-306-048-AL1-02	Base Panel	1	2/2
3	S300-306-048-AL1-03	Drawer Top Panel	1	2/2
4	S300-306-048-AL1-04	Right Side Panel	1	1/2
5	S300-306-048-AL1-05	Top Panel	1	2/2
6	S300-306-048-AL1-06	Back Panel	6	1/2
7	S300-306-048-AL1-07	Adjustable Shelf	2	2/2
8	S300-306-048-AL1-08	Drawer Front	2	1/2
9	S300-306-048-AL1-09	Drawer Side	4	1/2
10	S300-306-048-AL1-10	Drawer Back Panel	2	1/2
11	S300-306-048-AL1-11	Drawer Bottom	2	2/2

# FITTINGS LIST

<p><b>A</b></p>  <p>+/2 Flat Head Screw Ø3,0 x 12mm (20x)</p>	<p><b>B</b></p>  <p>+/1 Flat Head Screw Ø3,5 x 12mm (4x)</p>	<p><b>C</b></p>  <p>+/2 Flat Head Screw Ø4,5 x 16mm (16x)</p>	<p><b>D</b></p>  <p>+/2 Dowel Ø6,0 x 30mm (28x)</p>
<p><b>E</b></p>  <p>+/2 Flat Head Screw Ø4,0 x 50mm (12x)</p>	<p><b>F</b></p>  <p style="text-align: center;">Handle (2x)</p>		<p><b>G</b></p>  <p>+/1 Cam Bolt (8x)</p>
<p><b>H</b></p>  <p>+/1 Cam Nut (8x)</p>	<p><b>I</b></p>  <p>+/2 Hole Plugs (28x)</p>	<p><b>J</b></p>  <p style="text-align: center;">Drawer Runners 300mm (2x)</p>	
<p><b>K</b></p>  <p>+/2 Nail 10 x 10 (54x)</p>	<p><b>L</b></p>  <p style="text-align: center;">FOOT (4x)</p>	<p><b>M</b></p>  <p style="text-align: center;">Glue (2x)</p>	
<p><b>N</b></p>  <p>+/1 Support Pin (8x)</p>	<p><b>O</b></p>  <p>+/1 Flan Head Screw Ø3,5 x 22mm (1x)</p>	<p><b>P</b></p>  <p>+/1 Washer (2x)</p>	<p><b>Q</b></p>  <p style="text-align: center;">Strap (1x)</p>
<p><b>R</b></p>  <p style="text-align: center;">Back Panel Strip (4x)</p>		<p><b>S</b></p>  <p>+/1 Back Panel Bracket (4x)</p>	



## TIPS FOR FITTINGS CAM-LOCKS

WHEN FITTING CAM NUT. ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE


↑

**CORRECT**

✗


**WRONG**




**Cam bolt head needs to be in centre**

### **CAMBOLT**

Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)




**Shoulder**



✗

**Panel**



✓



**Panel**

# STEP 1




## PARTS REQUIRED

- 1 - LEFT SIDE PANEL x1
- 3 - DRAWER TOP PANEL x1
- 4 - RIGHT SIDE PANEL x1

## HARDWARE REQUIRED

- D  12  
Ø6,0 x 30mm
- M  01

## TOOLS REQUIRED





# STEP 2





## PARTS REQUIRED

- 1 - LEFT SIDE PANEL x1

## HARDWARE REQUIRED

- A  04  
Ø3,0 x 12mm
- J  02  
Left

## TOOLS REQUIRED





# STEP 3

## PARTS REQUIRED





4 - RIGHT SIDE PANEL x1

## HARDWARE REQUIRED

A  04  
Ø3,0 x 12mm

J  02  
Right

## TOOLS REQUIRED




# STEP 4

## PARTS REQUIRED

1 - LEFT SIDE PANEL x1





2 - BASE PANEL x1

## HARDWARE REQUIRED

E  02  
Ø4,0 x 50mm

M  01  
Glue


## TOOLS REQUIRED




# STEP 5

## PARTS REQUIRED

3 - DRAWER TOP PANEL x1






## HARDWARE REQUIRED


E  02  
Ø4,0 x 50mm

M  01

## TOOLS REQUIRED



Detail 5




Detail 6


# STEP 6


## PARTS REQUIRED

4- RIGHT SIDE PANEL x1






## HARDWARE REQUIRED


E  04  
Ø4,0 x 50mm

M  01

## TOOLS REQUIRED




Detail 5





Detail 6

# STEP 7




## PARTS REQUIRED




## HARDWARE REQUIRED



## TOOLS REQUIRED



Detail 7




PLEASE NOTE  
PRE-DRILLED  
HOLES.



# STEP 8

## PARTS REQUIRED




5 - TOP PANEL x1




## HARDWARE REQUIRED



## TOOLS REQUIRED



Detail 5




Detail 6


# STEP 9


## PARTS REQUIRED

6 - BACK PANEL x6





## HARDWARE REQUIRED

K  38  
10 x 10




R  04

S  04

## TOOLS REQUIRED




\* For your future reference  
Order Number should be here






# STEP 10




**PARTS REQUIRED**




**HARDWARE REQUIRED**



**TOOLS REQUIRED**



**Detail 10**





**Detail 11**

# STEP 11




**PARTS REQUIRED**



**HARDWARE REQUIRED**



**TOOLS REQUIRED**




**Detail 2**

# STEP 12




**PARTS REQUIRED**

10 - DRAWER BACK PANEL x2

**HARDWARE REQUIRED**

G  04

**TOOLS REQUIRED**




# STEP 13




**PARTS REQUIRED**

8 - DRAWER FRONT x2

**HARDWARE REQUIRED**

G  04

**TOOLS REQUIRED**



# STEP 14

## PARTS REQUIRED

9 - DRAWER SIDE x4

10 - DRAWER BACK PANEL x2




## HARDWARE REQUIRED

H  04


I  04

M  01


## TOOLS REQUIRED



Detail 2



Detail 4




Cam bolt head needs to be in centre


# STEP 15

## PARTS REQUIRED

8 - DRAWER FRONT x2






## HARDWARE REQUIRED

H  04


I  04

M  01


## TOOLS REQUIRED



Detail 5



Detail 4




Cam bolt head needs to be in centre


# STEP 16

**PARTS REQUIRED**





11 - DRAWER BOTTOM x2



**HARDWARE REQUIRED**


K  10 x 10 16

**TOOLS REQUIRED**





# STEP 17

**PARTS REQUIRED**






**HARDWARE REQUIRED**

A  Ø3.0 x 12mm 08

J  LEFT 02


J  RIGHT 02

**TOOLS REQUIRED**




# STEP 18




## PARTS REQUIRED



## HARDWARE REQUIRED





## TOOLS REQUIRED





# STEP 19

## PARTS REQUIRED


7 - ADJUSTABLE SHELF x2





## HARDWARE REQUIRED



## TOOLS REQUIRED



**TIP**  
If desired, after assembly use an alcohol cleaner to erase the number printed on the parts.



## WARNING

**Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.**

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices.

Please make sure you use fixings suitable for the walls in your home.

