


SAXTON 1 DOOR 3 DRAWER SIDEBOARD ASSEMBLY INSTRUCTIONS



IMPORTANT FOR DOMESTIC USE ONLY PLEASE READ BEFORE YOU CONTINUE FURTHER

THE PRODUCT YOU HAVE PURCHASED WILL GIVE YOU MANY YEARS OF SERVICE IF YOU FOLLOW THE GUIDELINES FOR ITS SAFE ASSEMBLY AND PERIODIC MAINTENANCE AND CLEANING.

ASSEMBLE ON A SOFT CLEAN SURFACE.

DO NOT USE ANY TOOLS OTHER THAN THOSE SHOWN.


ANY SPANNERS OR ALLEN KEYS REQUIRED ARE INCLUDED WITH THE FITTINGS KIT.

DO NOT FOR ANY REASON USE A POWER TOOL TO ASSEMBLE THIS PRODUCT. ITS USE WILL INVALIDATE ANY CLAIM YOU MAY HAVE AND COULD MAKE THIS PRODUCT UNSAFE.

DEPENDING ON THE AMOUNT OF USE THIS PRODUCT RECEIVES IT MAY BE NECESSARY TO TIGHTEN UP THE FIXINGS FROM TIME TO TIME. THIS IS COMPLETELY NORMAL FOR ANY FLAT PACK FURNITURE. DO NOT OVERTIGHTEN FIXING.

FOR CLEANING, YOU MAY USE A DAMP CLOTH (NOT WET) DO NOT USE POLISH, DETERGENT OR CHEMICAL CLEANERS.


THE SURFACE OF THIS ITEM IS NOT HEAT RESISTANT. ALWAYS USE A PLACE MAT UNDER HOT OR COLD ITEMS TO PREVENT MARKING.




PART LIST

<u>Part Number</u>	<u>Part Code</u>	<u>Part Description</u>	<u>Quantity</u>	<u>Carton</u>
1	S400-405-041-EU1-01	Shelf Panel	2	2/2
2	S400-405-041-EU1-02	Left Side Panel	1	2/2
3	S400-405-041-EU1-03	Right Side Panel	1	2/2
4	S400-405-041-EU1-04	Centre Panel	1	2/2
5	S400-405-041-EU1-05	Back Panel	1	1/2
6	S400-405-041-EU1-06	Bottom Panel	1	1/2
7	S400-405-041-EU1-07	Leg	4	2/2
8	S400-405-041-EU1-08	Top Panel	1	1/2
9	S400-405-041-EU1-09	Drawer Back	3	2/2
10	S400-405-041-EU1-10	Drawer Side - Left	3	2/2
11	S400-405-041-EU1-11	Drawer Side - Right	3	2/2
12	S400-405-041-EU1-12	Drawer Front	3	2/2
13	S400-405-041-EU1-13	Drawer Base	3	2/2
14	S400-405-041-EU1-14	Door	1	1/2
15	S400-405-041-EU1-15	Large Shelf Panel	1	2/2


HARDWARE LIST

A		DOWEL 6 X 30MM	56 PCS
B		SCREW M6 X 50MM	11 PCS
C		SCREW M3.5 X 20MM	16 PCS
D		CAM BOLT + CAM NUT	17 SETS
E		ALLEN KEY	1 PC
F		ANGLED LEG FIXING PLATE	4 PCS
G		CAP	17 PCS
H		DRAWER RUNNER A - L/R	6 PCS
I		DRAWER RUNNER B - L/R	6 PCS
J		HANDLE	4 PCS
K		HANDLE SCREW 25MM	8 PCS
L		SCREW M4 X 38MM	6 PCS
M		SCREW M3.5 X 16MM	22 PCS
N		SCREW M3.5 X 12MM	39 PCS
O		BOLT M6 X 50MM	12 PCS
P		SHELF SUPPORT	4 PCS
Q		HINGES 5/8	2 PCS
R		TAPPING SCREW M8 X 12MM	4 PCS
S		ANTI - TIP STRAP	2 PCS
T		SCREW M4 X 16MM	2 PCS



(SCREWDRIVER NOT PROVIDED)

USE A FLAT HEAD SCREWDRIVER TO TIGHTEN THE CAM NUTS. A QUARTER TURN CLOCKWISE IS ALL THAT IS NEEDED.



STEP 1 - USE A CROSS SLOT SCREWDRIVER TO TIGHTEN THE CAM BOLT INTO THE HOLE.

STEP 2 - ALIGN THE CAM BOLT WITH THE HOLE AND PUSH TOGETHER UNTIL FLUSH. (MAKE SURE THE ARROW OF THE CAM LOCK IS POINTING TOWARD ON THE EDGE OF THE PANEL.)

STEP 3 - THE HEAD OF THE BOLT GOES INTO THE WIDE MOUTH OF THE CAM LOCK. YOU THEN TURN THE LOCK SO THE NARROW PART CLOSES OVER THE BOLT.

STEP 1



PARTS REQUIRED

1 - SHELF PANEL x2

HARDWARE REQUIRED

A  06

TOOLS REQUIRED



STEP 2

PARTS REQUIRED

2 - LEFT SIDE PANEL x1




HARDWARE REQUIRED

A  06

D  02

P  02

TOOLS REQUIRED



STEP 3



PARTS REQUIRED

3 - RIGHT SIDE PANEL x1

HARDWARE REQUIRED

- A  06
- D  02
- H  03
- N  12

TOOLS REQUIRED




STEP 4



PARTS REQUIRED

4 - CENTRE PANEL x1

HARDWARE REQUIRED

- A  06
- D  02
- H  03
- N  12
- P  02

TOOLS REQUIRED



STEP 5

PARTS REQUIRED



5 - BACK PANEL x1

HARDWARE REQUIRED

A  08

D  05

TOOLS REQUIRED



STEP 6



PARTS REQUIRED

8 - TOP PANEL x1

HARDWARE REQUIRED

D  11

TOOLS REQUIRED




STEP 7


PARTS REQUIRED

- 1 - SHELF PANEL x2
- 2 - LEFT SIDE PANEL x1
- 3 - RIGHT SIDE PANEL x1

HARDWARE REQUIRED




TOOLS REQUIRED



STEP 8


PARTS REQUIRED

- 4 - CENTRE PANEL x1
- 5 - BACK PANEL x1




HARDWARE REQUIRED

TOOLS REQUIRED




STEP 9


PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED



STEP 10

PARTS REQUIRED


6 - BOTTOM PANEL x1



HARDWARE REQUIRED



TOOLS REQUIRED




STEP 11

PARTS REQUIRED



HARDWARE REQUIRED

TOOLS REQUIRED


EXAMPLE FOR ASSEMBLING ON STEP 12



(A) THE HIGHER PART
(B) THE LOWER PART




MAKE SURE THE HIGHER SIDE OF PART (F) IS POINTING TOWARD THE CENTRE (A) AND THE LOWER SIDE (B) IS POINTING OUTWARD.



STEP 12

PARTS REQUIRED





HARDWARE REQUIRED

C  **16**

F  **04**


TOOLS REQUIRED



STEP 13


PARTS REQUIRED

7 - LEG x4



HARDWARE REQUIRED


TOOLS REQUIRED



STEP 14



PARTS REQUIRED

8 - TOP PANEL x1




HARDWARE REQUIRED

TOOLS REQUIRED



STEP 15


PARTS REQUIRED



HARDWARE REQUIRED

G		11
---	--	----

TOOLS REQUIRED



STEP 16



PARTS REQUIRED

9 - DRAWER BACK	x3
10 - DRAWER SIDE - LEFT	x3
11 - DRAWER SIDE - RIGHT	x3
12 - DRAWER FRONT	x3

HARDWARE REQUIRED

A		24
D		06

TOOLS REQUIRED



STEP 17



PARTS REQUIRED

9 - DRAWER BACK	x3
10 - DRAWER SIDE - LEFT	x3
11 - DRAWER SIDE - RIGHT	x3
12 - DRAWER FRONT	x3

HARDWARE REQUIRED

L		06
---	---	----


TOOLS REQUIRED




STEP 18

PARTS REQUIRED

13 - DRAWER BASE	x3
------------------	----





HARDWARE REQUIRED

I		06
---	---	----

M		18
---	---	----


N		15
---	---	----

TOOLS REQUIRED




STEP 19



PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED




STEP 20



PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED




STEP 21

PARTS REQUIRED

14 - DOOR x1

15 - LARGE SHELF PANEL x1





HARDWARE REQUIRED

J  01

K  02


R  04

TOOLS REQUIRED




STEP 22

PARTS REQUIRED




X3



HARDWARE REQUIRED

TOOLS REQUIRED




STEP 23

PARTS REQUIRED



HARDWARE REQUIRED

TOOLS REQUIRED



STEP 24


PARTS REQUIRED



HARDWARE REQUIRED

S		02
T		02

TOOLS REQUIRED



WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.

