


ASSEMBLY INSTRUCTIONS



FOR DOMESTIC USE ONLY

IMPORTANT

PLEASE READ BEFORE YOU CONTINUE FURTHER

THE PRODUCT YOU HAVE PURCHASED WILL GIVE YOU MANY YEARS OF SERVICE IF YOU FOLLOW THE GUIDELINES FOR ITS SAFE ASSEMBLY AND PERIODIC MAINTENANCE AND CLEANING.

ASSEMBLE ON A SOFT CLEAN SURFACE.

DO NOT USE ANY TOOLS OTHER THAN THOSE SHOWN.


ANY SPANNERS OR ALLEN KEYS REQUIRED ARE INCLUDED WITH THE FITTINGS KIT.

DO NOT FOR ANY REASON USE A POWER TOOL TO ASSEMBLE THIS PRODUCT.ITS USE WILL INVALIDATE ANY CLAIM YOU MAY HAVE AND COULD MAKE THIS PRODUCT UNSAFE.

DEPENDING ON THE AMOUNT OF USE THIS PRODUCT RECEIVES IT MAY BE NECESSARY TO TIGHTEN UP THE FIXINGS FROM TIME TO TIME.THIS IS COMPLETELY NORMAL FOR ANY FLAT PACK FURNITURE.DO NOT OVERTIGHTEN FIXING.





FOR CLEANING, YOU MAY USE A DAMP CLOTH (NOT WET) DO NOT USE POLISH, DETERGENT OR CHEMICAL CLEANERS.

THE SURFACE OF THIS ITEM IS NOT HEAT RESISTANT. ALWAYS USE A PLACE MAT UNDER HOT OR COLD ITEMS TO PREVENT MARKING.



(SCREWDRIVER NOT PROVIDED)

USE A FLAT HEAD SCREWDRIVER TO TIGHTEN THE CAM NUTS. A QUARTER TURN CLOCKWISE IS ALL THAT IS NEEDED.




STEP 1 - PUSH CAM BOLT INTO INSERT

STEP 2 - ALIGN THE CAM BOLT WITH THE HOLE AND PUSH TOGETHER UNTIL FLUSH. (MAKE SURE THE ARROW OF CAM LOCK IS POINTING TOWARD THE HOLE ON EDGE OF PANEL.)


STEP 3 - THE HEAD OF THE BOLT GOES INTO THE WIDE MOUTH OF THE CAM LOCK. YOU THEN TURN THE LOCK SO THE NARROW PART CLOSES OVER THE BOLT.

! CAUTION : THE USE OF POWER TOOLS TO ASSEMBLE THIS PRODUCT WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.



PARTS LIST


PLEASE CHECK THAT YOU HAVE ALL THE PARTS LISTED BEFORE YOU START ASSEMBLING. IF YOU DO FIND THAT SOMETHING IS MISSING, DO NOT CONTINUE ASSEMBLY, PLEASE CONTACT YOUR SUPPLIER IMMEDIATELY.





PARTS LIST

1	RIGHT SIDE PANEL	1 PC
2	TOP PANEL	1 PC
3	CENTRE SHELF	1 PC
4	BASE PANEL	1 PC
5	FRONT / BACK PLINTH	2 PCS
6	BACK CROSSBAR	2 PCS
7	LEFT SIDE PANEL	1 PC
8	BACK PANEL	2 PCS
9	TOP FRAME	1 PC
10	DOOR 1	1 PC
11	DOOR 2	1 PC
12	DRAWER BACK	2 PCS
13	DRAWER SIDE - LEFT	2 PCS
14	DRAWER SIDE - RIGHT	2 PCS
15	DRAWER FRONT	2 PCS
16	DRAWER BASE	2 PCS
17	DRAWER BOTTOM SUPPORT RAIL	2 PCS

! CAUTION: THE USE OF POWER TOOLS TO ASSEMBLE THIS PRODUCT WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.




HARDWARE LIST

A		DOWEL 6 X 30MM	44 PCS
B		BOLT M6 X 50MM	20 PCS
C		SCREW M3.5 X 16MM	28 PCS
D		TACK	30 PCS
E		SCREW M4 X 38MM	8 PCS
F		HANDLE	4 PCS
G		TAPPING SCREW 8 X 12MM	12 PCS
H		HANGING RAIL SUPPORT	2 PCS
I		HANGING RAIL	1 PC
J		PLASTIC H STRIP	1 PC
K		SCREW 3.5 X 12MM	20 PCS
L		CAM BOLT + CAM NUT	4 SETS
M		HINGES	6 PCS


N		DRAWER RUNNER A	4 PCS
O		DRAWER RUNNER B	4 PCS
P		HANDLE SCREW 30MM	8 PCS
Q		PVC LEG	1 SET
R		SCREW M4 X 25MM	5 PCS
S		ALLEN KEY	1 PC
T		SCREW M4 X 30MM	4 PCS
U		PVC LEG	2 PCS
V		ANTI - TIP STRAP	2 PCS
W		SCREW M4 X 16MM	2 PCS

! **CAUTION:** THE USE OF POWER TOOLS TO ASSEMBLE THIS PRODUCT WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.



STEP 1


YOU WILL NEED:-		
H		2 PCS
K		20 PCS
N		4 PCS




SCREW MUST BE INSERTED IN THE FIRST HOLE ON THE DRAWER RUNNER

STEP 2

YOU WILL NEED:-		
A		12 PCS




! CAUTION: THE USE OF POWER TOOLS TO ASSEMBLE THIS PRODUCT WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.



STEP 3

YOU WILL NEED:-


A		20 PCS
---	---	--------




STEP 4

YOU WILL NEED:-


C		12 PCS
F		2 PCS
M		6 PCS
P		4 PCS



! **CAUTION:** THE USE OF POWER TOOLS TO ASSEMBLE THIS PRODUCT WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.




STEP 5.1




YOU WILL NEED:-

B		8 PCS
S		1 PC

STEP 5.2




STEP 6




YOU WILL NEED:-

B		12 PCS
S		1 PC

! CAUTION: THE USE OF POWER TOOLS TO ASSEMBLE THIS PRODUCT WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.





STEP 7.1




YOU WILL NEED:-

D		16 PCS
J		1 PC






STEP 7.2




STEP 8

YOU WILL NEED:-


C		4 PCS
Q		1 SET
U		2 PCS



CAUTION : THE USE OF POWER TOOLS TO ASSEMBLE THIS PRODUCT WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.






STEP 9




YOU WILL NEED:-

R		5 PCS
---	--	-------





BEFORE FIXING THE TOP FRAME PLEASE ALIGN WITH TOP PANEL

STEP 10




YOU WILL NEED:-


G		12 PCS
I		1 PC



1. VERTICAL ADJUSTMENT VIA SLOT IN THE MOUNTING PLATE




2. LATERAL ADJUSTMENT BY SCREW ADJUSTING




3. FRONT-TO-BACK BY THE SLACKING THE HINGE ARM MOUNTING SCREW

YOU SHOULD RE-ADJUST SCREWS AS SHOWN ABOVE TO ALIGN DOOR ONCE HINGES HAVE BEEN ATTACHED.


! CAUTION: THE USE OF POWER TOOLS TO ASSEMBLE THIS PRODUCT WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.




STEP 11.1



STEP 11.2



STEP 11.3




YOU WILL NEED:-

A		12 PCS
C		12 PCS
D		14 PCS
E		8 PCS
F		2 PCS
L		4 SETS
O		4 PCS
P		4 PCS
T		4 PCS


THIRD HOLE
LAST THIRD HOLE
FRONT

STEP 11.4


2 X DRAWER




STEP 11.5





STEP 11.6




! CAUTION: THE USE OF POWER TOOLS TO ASSEMBLE THIS PRODUCT WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.



STEP 12**STEP 13**

CAUTION: THE USE OF POWER TOOLS TO ASSEMBLE THIS PRODUCT WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.



WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.




HARDWARE LIST



(V) Anti-Tip Strap - 2 pcs



(W) M4 X 16MM - 2 pcs



! **CAUTION:** THE USE OF POWER TOOLS TO ASSEMBLE THIS PRODUCT WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.

